

ultego III perfect – highest precision and reliability



Reliable Measurement


Longevity, measuring stability and a high dynamic range distinguish the ultego III perfect. Even after operating for years in the

district heating water environment with low conductivity the ultego III perfect is measuring the volume precisely and reliably. Due to the patented DuraSurface, we are

setting new standards in measurement stability. This future-oriented innovation ensures measuring accuracy and maintenance-free operation for many years.

Technical data

Nominal flow Q_n/Q_p	m^3/h	3.5	6	10	15	25	40	60
Meteorological Class		1:100	1:100	1:100	1:100	1:100	1:100	1:100
Maximum flow rate Q_s	m^3/h	7.0	12	20	30	50	80	120
Minimum flow rate Q_i	l/h	35	60	100	150	250	400	600
Response limit	l/h	14	24	40	60	100	160	240
Pressure loss Δp at Q_p								
Thread	mbar	65	150	100	–	–	–	–
Flange	mbar	65	150	165	100	105	160	115
Pressure loss $\Delta p = 1$ bar								
Thread	$K_v m^3/h$	14	15	32	–	–	–	–
Flange	$K_v m^3/h$	14	15	32	48	77	100	177
Installation position					Variable			
Temperature range limit values					5...130 °C			
Maximum temperature	t_{max}				150 °C for 2000h			
Nominal pressure	PN			1.6 MPa (PN16)		2.5 MPa (PN25)		1.6 MPa (PN16)
				2.5 MPa (PN25)		2.5 MPa (PN25)		2.5 MPa (PN25)
Permissible metering error acc. EN 1434 (Class 2)					2 + 0.02 q_p/q %			
					max. 5%			



Safety information

- Do not pick up by the electronic unit
- Be careful of sharp edges (thread, flange, measuring tube)
- Installation and removal must be performed by qualified personnel only
- Mounting and unmounting are only permitted when the system is not under pressure
- After installation, a tightness test must be conducted with cold pressure
- Only ever use under service conditions, otherwise dangers can arise and the warranty may be voided
- Breaking the calibration seal voids the warranty
- The 110 V / 230 V versions must only be connected by an electrician
- The lithium batteries must be properly returned
- Lightning protection cannot be ensured; this must be provided by the building wiring
- Only one compartment for the power supply must be equipped – do not remove the red locking hatch



General information

The electronic unit is plugged onto an adapter plate and can be separated by pushing the volume measuring unit upward. The packaging should be kept so that the heat meter can be shipped in its original packing after the calibration period has elapsed.

If the heat meter was not supplied with a battery connected, the current date and time must be entered during start-up (see "Parameter setting").

The 110 V / 230 V power supply units comply with safety class II, so the line voltage does not need to be disconnected when changing the unit.

All cables must be laid at a minimum distance of 300 mm from power cables or radio-frequency cables.

By overpressure, cavitation must be avoided in the entire measuring range, i.e. at least 1 bar at qp and approx. 3 bar at qs (applies to approx. 80°C).

The heat meter left the factory in perfect safe condition. Calibration, maintenance, component replacement, and repairs must only be performed by trained personnel who are familiar with the hazards involved. The manufacturer will provide further technical support on request. Heat meter safety marks that are relevant for calibration must not be damaged or removed! Otherwise the warranty and calibration validity of the device will expire.



Installation

Choose the mounting location (return or flow) in accordance with the labeling on the heat meter. Study the table for the dimensions and check that there is enough clearance.


No inlet or outlet sections are necessary. However, if the heat meter is installed in the shared return of two heating systems, e.g. heating and hot water, the mounting location must be a sufficient distance from the T element that forms the junction (min. 10°xDN) to allow the different water temperatures to mix well.

Before the heat meter is installed, the system must be rinsed thoroughly.


As shown in the examples on Page 2, mount the volume measuring unit horizontally or vertically between two shut-off valves in accordance with the arrow for the direction of flow. The sensors must be mounted in the same heating circuit as the volume measuring unit. For installation as a cold meter, see the following notes.

The sensor can be mounted in ball valves, in pockets or direct immersed. The end of the sensors must extend in any case as far as the center of the pipe cross-section. Temperature sensors and screw joints must be sealed for protection from tampering.


Small heat meters (qp 0.6 - 2.5 m³/h)




Overall length 110 mm
(thread)



Overall length 130 mm
(thread)




Overall length 190 mm (thread)



Overall length 190 mm (flange)


Large heat meters with threaded joint

alternative mounting option




qp m³/h	PN bar	a	b	c
3.5	16	260	51	G 1 1/4 B
3.5	25	260	51	G 1 1/4 B
6	16	260	51	G 1 1/4 B
10	16	300	48	G 2 B

Large heat meters with flange joint




qp m³/h	PN bar	DN	a	b	Øc	Ød	Øe	No of holes	f	g
3.5	25	25	260	51	115	85	14	4	68	18
6	25	25	260	51	115	85	14	4	68	18
10	25	40	300	48	150	110	18	4	88	18
15	25	50	270	46	165	125	18	4	102	20
25	25	65	300	52	185	145	18	8	122	22
40	25	80	300	56	200	160	18	8	138	24
60	16	100	360	68	235	180	18	8	158	24
60	25	100	360	68	235	190	22	8	158	24

Examples of installation



Example of mounting with a ball valve
(recommended up to DN25)



Example of mounting with pockets
(recommended for > DN25)


Electronic unit



The ambient temperature of the electronic unit must not exceed 55°C. Direct sunlight must be avoided.

For heating water temperatures between 10°C and 90°C, the electronic unit can remain on the volume measuring unit or be mounted on the wall (split mounting). On the wall or on the volume measuring unit, the adapter plate can be oriented to make it easy to read the display. To remove the electronic unit, push the housing upward and remove. The adapter plate for wall mounting can now be unscrewed or the electronic unit simply rotated and pushed back into the required position until it latches.

For heating water temperatures between 10°C and 90°C, the electronic unit must be fixed on the wall (split mounting). For this purpose, remove the electronic unit from the adapter plate, unscrew the adapter plate from the volume measuring unit, and screw to the wall with plugs. Push the electronic unit on again.

A heat meter with a removable control cable may be separated during the installation. When installation is done be sure that only paired parts (volume part, calculator) are connected together. The control cable must not be extended!



	<h3>Mounting as a cold meter</h3> <p>When mounting a cold meter or combined heat/cold meter, make sure the black cover on the measuring tube is oriented to the side and downward (because of water condensation). The electronic unit must be separated from the flowrate measuring tube and, for example, mounted on the wall (split mounting). Make sure that condensed water cannot run along the connected pipes into the electronic unit (building a loop downwards).</p> <p>Allowed position of the cold meter</p> 
i	<h3>Power supply</h3> <p>The heat meter can be powered either with a battery or via power supply modules. The 110 V / 230 V power supply modules are encapsulated and comply with safety class II. The modules can be retrofitted or upgraded at any time.</p> <p>In the standard version, a battery is inserted in the factory. This must not be opened. It must not come into contact with water or be exposed to temperatures exceeding 80°C. Used batteries must be disposed of at suitable waste disposal facilities.</p> <p>In a special version, a power supply module can be installed. In the 110 V AC and 230 V AC versions, a cable is brought out in the factory that must be connected to the line voltage accordingly. The 24 V AC/DC version has terminals instead of a cable.</p> <p>The 110 V or 230 V power supply unit must be fuse-protected with 6 A near to the heat meter and protected from tampering.</p> 
S	<h3>Insert the battery</h3> <p>Press the four side tabs of the housing cover inward and remove the cover. Then turn the label plate counterclockwise until you feel it has gone as far as it will go.</p> <p>Swing open the red locking hatch to expose the relevant battery compartment (left compartment for 2x "AA" or "C", right compartment for "D").</p> <p>Insert the battery into the relevant compartment of the electronic unit with the correct polarity as marked.</p> <p>Turn the label plate back clockwise into its original position.</p> <p>NOTE:</p> <p>"AA" and "C" size batteries are snapped into a holder. In case of a meter's return via air freight the battery ("C" and "D" cell) has to be generally dismounted and forwarded separately from the meter.</p>

Mounting the power supply module

Instead of the battery, a power supply module (110 V / 230 V with connected cable, 24 V with terminals) can also be installed. This is done by moving the red locking hatch to the left to open the right-hand compartment for the power supply module. Remove the right-hand outside rubber sleeve upward, pull out the plugs and thread the connecting cable (line voltage) of the module through the sleeve. Insert the module in the upper right-hand corner of the electronic unit and re-insert the sleeve with the cable from above. Connect the conductors as labeled. Plug the other connecting cable (low voltage) onto the plug connector on the circuit board..



NOTE:

- For the 24 V AC/DC version, cable with a diameter greater than 5.0...6.0 mm should not be used!
- The 110 V / 230 V versions must only be connected by an electrician!

When replacing a unit after the calibration period has elapsed, swing out the power supply module with the cable and sleeve, mount the new heat meter, and re-insert the module. Because it complies with safety class II, the line power supply does not have to be disconnected.



Interfaces of the electronic unit


The UH50 heat meters are equipped with an optical interface per EN 62056-21:2002 as standard. Moreover, up to two of the following communication modules can be used for remote reading:

- Pulse module (pulses for quantity of heat / volume / unit status / tariff register 1 / tariff register 2; isolated, bounce-free)
- M-bus module per EN 1434-3, fixed and extended, variable protocol (also for coupling with a suitable heating controller)
- Analog module

These modules are have no effect on consumption metering and can therefore also be replaced at any time without violating the adhesive label.

Communication modules

In the lower right-hand area, up to two communication modules can be installed in the factory. At a later installation the necessary ESD protection measures has to be considered.



For further technical details and data on the module, see the technical documentation.

Terminals

2-pole and 4-pole terminals are used for connecting external cables to the modules.

- Strip-back length 5 mm
- Connection capacity
 - rigid or flexible, 0.2 - 2.5 mm²
 - flexible with end ferrules, 0.25 - 1.5 mm²
 - conductor sizes 26 - 14 AWG
- Multiple-conductor connection (2 conductors of same cross-section)
 - rigid or flexible, 0.2 – 0.75 mm²
 - flexible with end ferrules without plastic sleeve, 0.25 – 0.34 mm²
 - flexible with TWIN ferrules with plastic sleeve, 0.5 – 0.75 mm²
- Recommended screwdriver:
 - 0.6 x 3.5 mm
- Tightening torque: 0.4 Nm

Permissible combinations of modules

A pulse module with "fast" pulses must always be inserted as module 2.

**NOTE:**

Subsequent mounting of a further pulse module in module slot 1 can result in changed output values for module 2!

The radio module must also always be inserted as module 2.

Further restrictions are shown in the following table.

		Slot for module #2 is equipped with...		
		Pulse module "standard"	M-bus module	Analog module
Slot for module #1 can be equipped with ...	Pulse module "standard"	yes (2)	yes (1)	yes (3)
	"fast" *)	no	no	no
	M-bus module	yes	yes	yes (3)
	Analog module	yes	yes	yes (3)

*) only 1 module with fast pulses is possible, only permissible on slot 2; min. pulse duration = 2 ms, if pulse module 1 not fitted.

1. Pulse length of the fast pulses min. 5 ms
2. The first and second channel can be parameterized individually
3. The secondary address for both modules can only be changed via module No. 1

**Installing a communication module**

The communication modules are connected via a 6-way reaction-free connector so that installation or replacement is possible at any time.


Put the communication module in the correct position, carefully insert it into the two guide slots, and push it in.

For connection with the external cable, strip the sleeve to ensure the correct cross-section of the connecting cable. Feed the cable through the sleeve from outside, strip it back and connect it. A cable shield must not be connected to the heat meter. Ensure you use the correct slot for the modules and comply with the permissible combinations.

**Factory-installed sensors****NOTE:**

Do not disconnect, shorten, or extend the cables of factory-installed sensors.

Parameter setting



NOTE:

The housing cover has to be removed temporarily in order to operate the service button.



Setting the date / time

Units with a power supply unit or new battery connected in situ may start directly in the setting menu for the date and time..

I 100506	Enter the date
T 105959	Enter the time
N _E -----	Return to normal mode (manual)

Press LCD button 1 repeatedly until the required value is shown. Then press LCD button 2. Change the value for the date or time as described under *Performing parameter setting*.

Calling the parameter setting function

Press the service button for about 3 s. The LCD shows the display PRUEF----.

In this state, you can parameterize the tariffs and fast pulses using the PappaWin software.



CAUTION:

For fast pulses in battery operation, a D cell is required.

LCD button 1 advances the display.

PRUEF----	Call test mode
PArA----	Call parameter setting mode
N _E -----	Return to normal mode (manual)

Press LCD button 1 repeatedly until "PArA" is shown. Then press LCD button 2.
The following parameter settings are possible:

F8	+	Reset error message F8 (only displayed if F8 is pending)
M_u	+	Reset the maxima
F_d	+	Reset the missing time and the flowrate measuring time
S₁ 3 105,-		Enter the yearly set day (day and month) *)
S₁ 3 1--		Enter the monthly set day (day) *)
I 100506		Enter the date (day, month, year) *)
T 10,59,59		Enter the time (hour, minute, second) *)
K 12345678		Enter the property number, 8-digit (also M-bus secondary address)
AP1 0		Enter the M-bus primary address for module 1 (0..255) *)
AP2 0		Enter the M-bus primary address for module 2 (0..255) *)
Modul 1-1 CE		Select the first module function for module 1 (CE or C2)
Modul 1-1 C2		
Modul 1-2 CV		
Modul 1-2 CT		Select the second module function for module 1 (CV or CT or RI)
Modul 1-2 RI		
Modul 2-1 CE		Select the first module function for module 2 (CE or C2)
Modul 2-1 C2		
I 100506		
Modul 2-2 CT		Select the second module function for module 2 (CV or CT or RI)
Modul 2-2 RI		
MP 60 min		Select the maxima measuring period: 7.5-15-30-60 min / 3 6 12 24 h
N_b-----		Return to normal mode

*) It is up to the user to ensure that only meaningful values are entered. No plausibility check is made and "incorrect" values can be applied (month > 12 etc.)


NOTE:

The functions for modules 1 and 2 are also offered if no or any other module is plugged.
In this way, the heat meter can be parameterized before the modules are fitted.

The required size is selected with the LCD button 1 and activated with the LCD button 2.


NOTE:

Parameter setting can be exited by pressing the service button again ("escape function"). In this case, the last valid value is displayed unchanged.

Performing parameter setting

LCD button 2 is used to change the blinking digit step by step or reset error F8 or the maxima. LCD button 1 applies the value set in the blinking digit. The next digit to the right of this then blinks, can be set again with the LCD button 2 and can be applied with LCD button 1. As the final acknowledgment of a display line, a star symbol is briefly displayed. If incorrect entries are made, parameter setting be performed again.

Completing parameter setting

Parameter setting mode is exited:

- by pressing LCD button 2, when the display shows Nb-----
- Automatically after 15 hours

**Start-up**

Replace the housing cover and press it in gently until you hear all the tabs latch. Open the shut-off valves. Check the heating system for tightness and vent it carefully.

No more than 100 s later, message F0 will disappear. After that, check that the displays for flowrate and temperatures are plausible. Vent the system until the flowrate display is stable. Adjust the system with the flowrate display (updated in the flowrate timebase).

Seal the sensors. Attach user seals to the electronic unit and the sensors.

Read and note down the meter readings for quantity of heat, volume, operating time, and missing time.

We recommend resetting the maxima and the missing time (see parameter setting).

Error messages on incorrect mounting:

FL	nEG	Heat meter was mounted the wrong way round, against the intended direction flow
diff	nEG	Temperature sensors were swapped round during mounting or connection

**NOTE:**

During a system stoppage, these messages may appear although mounting was correct.

Displays

The places after the decimal point of displayed values are indicated by a surrounding border.

Calibrated values can be recognized by the star symbol shown in addition to the value.

The displays of the heat meter are arranged on several levels (LOOPS). LCD button 2 advances the display of the user loop (LOOP 0) cyclically.

**NOTE:**

Depending on how the unit is parameterized, the number of items displayed and the data shown may differ from this description. Certain button functions may also be disabled.

User loop ("LOOP 0")

LOOP 0	Head of the loop
... 1234567 kWh	Accumulated quantity of heat with tariff status
T' 1234567 kWh	Tariff register 1 (optional)
1234567 m³	Accumulated volume
8,8,8,8,8 kWh	Segment test
F -----	Error message with error code number

LCD button 1 is used to switch the display from the user loop to the selection of service loops (LOOP 1..n).

Service loops (selection)

LOOP 1	Service loop 1
LOOP 2	Service loop 2
...	...
LOOP n	Service loop n

LCD button 1 advances the display to the next loop. After the last loop, the user loop (LOOP 0) appears again.

LCD button 2 displays the content of the selected service loop.

Within a loop, the LCD button 2 is used to advance to the next line of the display. After the last line of the display, the first display line appears again.

Service loop 1 (“LOOP 1”)

L<small>OOP</small> 1	Head of the loop
1234 m/h	Current flowrate
90,9 kW	Current heat power
91 56 °C	Current flow/return temperature
3d 1234 h	Operating time
P<small>d</small> 1234 h	Operating time with flowrate
F<small>d</small> 123 h	Missing time
K 12345678	Property number, 8-digit
D 10,05,06	Date
S D 3 105--	Yearly set day (DD.MM)
T1234567 kW h	Quantity of heat previous year on set day
T1234567 m³	Volume for previous year on set day
FW 1 5-00	Firmware version

Service loop 2 (“LOOP 2”)

In service loop 2, the maxima are displayed. LCD button 2 calls the displays one after the other.

L<small>OOP</small> 2	Head of the loop
M<small>a</small> 3,899 m/h	Max. flowrate, at 2s intervals with date stamp
S<small>t</small> 13,12,05	
M<small>a</small> 288,9 kW	Max. power, at 2s intervals with date stamp
S<small>t</small> 11,12,05	
M<small>a</small> 98 87 °C	Max. temperatures, at 2s intervals with date stamp for flow and return maximum
S<small>t</small> 08,12,05	
S<small>t</small> 04,12,05	
MP 60 min	Measuring period for maximum calculation

Service loop 3 (“LOOP 3”)

Service loop 3 shows the monthly values. LCD button 1 is used to select a month out of the 18 previous months. The data for that month are then opened with LCD button 2. Each further press of LCD button 2 shows the next value for the selected month.

LOOP 3	Head of the loop
0 0 06 M	Set day for December 2005
0 0 05 M	Set day for November 2005
...	...
0 0 04 M	Set day for July 2004
	using LCD button 2: ↓
123456,7 kWh	Quantity of heat on the set day
T 1234567 kWh	Tariff register 1 on the set day
1234567 m³	Volume on the set day
M_u 3,899 m³/h St 13,12,05	Max. flowrate on the set day, at 2s intervals with date stamp
M_u 2889 kW St 13,12,05	Max. heat power on the set day, at 2s intervals with date stamp
M_u 98 87 °C St 08,12,05 St 04,12,05	Max. temperatures on the set day, at 2s intervals with date stamp for flow and return maximum
Fd 123 h	Missing time count on the set day

After the last display, the previously selected set day is displayed again. Pressing LCD button 1 selects the next set day.

**NOTE:**

If you want to drop out and go directly to the next loop, choose a monthly value by pressing LCD button 2 and then press LCD button 1.

Service loop 4 (“LOOP 4”)

Service loop 4 shows the unit parameters. LCD button 2 calls the displays one after the other.

L0OP 4	Head of the loop
T2 0,000 m³/h ‘ 0,000 m³/h	Current tariff, at 2s intervals with threshold value 1
FP 200 SEC	Measuring interval for flowrate
TP 30 SEC	Measuring interval for temperature
Modul 1 M 1	Module 1: M-bus module
AP1 127	M-bus primary address 1
A 12345678	M-bus secondary address 8-digit
Modul 2-1 CE Modul 2-2 CV	Module 2: pulse module; chan. 1 = heat quantity Channel 2 = volume, at 2s intervals
P01 125,00 Wh //	Significance for heat quantity pulses *)
P02 0,0250 L//	Significance for volume pulses *)
P03 2ms	Pulse duration in ms *)
*) for “fast pulses”	

Previous year's values

The electronic unit stores the current meter readings for quantity of heat, volume, the tariff register, missing time, and flowrate measuring time as well as the service life maxima for flowrate, power, temperature difference, flow temperature, and return temperature with their date stamps on a yearly set day.

Monthly values

The electronic unit stores the meter readings for quantity of heat, volume, the tariff register, missing time, and flowrate measuring time as well as the monthly maxima for flowrate, power, temperature difference, flow temperature and return temperature with their date stamp for 18 months on the set day of each month.

**NOTE:**

The standard time used is Central European Time (CET). If daylight-saving time is activated, storage will be performed accordingly.

The monthly values can also be read out via the optical and the 20 mA interface.

Error messages

The heat meter constantly performs self-diagnostics and can display various error messages.

Errorcode	Error / action to be taken
F0	No flow; Air in measuring unit / pipe, vent pipe
F1	Interruption of flow sensor
F2	Interruption of return sensor
F3	Electronic for temperature evaluation defective
F4	Battery empty; replace!
F5	Short-circuit flow sensor
F6	Short-circuit return sensor
F7	Fault in the internal memory
F8	F1, F2, F3, F5 or F6 pending for longer than 8 hours. No more measurements are performed.
F9	Error in the electronics

Message F8 has to be reset in parameter setting mode (manually, PappaWin). All other error messages are cleared automatically once the error has been corrected.

	<p>Functional details</p> <p>If the response thresholds are exceeded and the flowrate and temperature difference are positive, the quantity of thermal energy and the volume are summated. In the segment test, all segments of the display are switched on for test purposes. On the yearly set day, the meter readings for quantity of heat and volume, the values for the service life maxima and the flowrate and missing times are placed in the previous year memory.</p> <p>The flowrate, heat power, and temperature difference are acquired with the correct sign. If the response threshold is not reached, the value is preceded by a u. The current temperatures are shown together on one line of the display as integers in °C. To calculate the maximum, the heat power and flowrate are averaged over a measuring period of, for example, 60 min. The maximum values from the average calculation are preceded by Ma on the LC display.</p> <p>The 8-digit property number (also the secondary address in M-bus operation), can be set in parameter setting mode. The unit number is assigned by the manufacturer.</p> <p>The operating time is counted from the first time the power supply is connected. Missing times are summated, if an error is pending that prevents the heat meter from measuring. The date is incremented daily.</p> <p>The type of installed modules is displayed. If an M-but module is installed, the primary and secondary address will be displayed on the following lines.</p> <p>The number for the firmware version is assigned by the manufacturer.</p>		
	<p>Notes</p> <ul style="list-style-type: none"> ▪ Regulations on the use of heat meters must be observed, see EN 1434, Part 6! ▪ In particular, cavitation in the system must be avoided. ▪ Heat meters up to DN25 may only be installed with directly immersed sensors according to German calibration law! ▪ Install the unit in such a way that no water can enter the electronic unit during operation. ▪ All information given on the data sheet of the heat meter must be observed. ▪ User seals may only be removed by authorized persons for service purposes and must be replaced afterwards. ▪ No later than 30 seconds after installation, the heat meter detects the plugged modules automatically and is ready for communication or pulse output. ▪ The type of modules plugged can be displayed in the service loop depending on how the display is parameterized. ▪ For fast pulses, the parameters must be set accordingly with the PappaWin software. ▪ Up-to-date versions of all instructions can be found in the Internet at www.ista.com 		
	<p>EC Declaration of conformity</p> <p>Landis+Gyr herewith declares that this product complies with the relevant requirements of the following directives:</p> <ul style="list-style-type: none"> ▪ 2004/22/EC measuring instruments directive *) ▪ 89/336/EEC electromagnetic compatibility ▪ 73/23/EEC low-voltage directive ▪ *) for Cold Meters applies PTB TR K 7.2 <table border="1" data-bbox="228 1365 1440 1432"> <tr> <td style="text-align: center;">EU typegodkendelsescertifikat DE-06-MI004-PTB018</td><td style="text-align: center;">EU-design-godkendelsescertifikat DE-06-MI004-PTB010</td></tr> </table>	EU typegodkendelsescertifikat DE-06-MI004-PTB018	EU-design-godkendelsescertifikat DE-06-MI004-PTB010
EU typegodkendelsescertifikat DE-06-MI004-PTB018	EU-design-godkendelsescertifikat DE-06-MI004-PTB010		